

## TRANSFER CONDITIONS PIONEER VALLEY WATER SUPPLY SCHEME

These local transfer conditions are to be read in conjunction with the conditions as set out on the Temporary Transfer Application Form.

### Loss Adjustments

Under normal conditions there are no loss adjustments for the scheme. SunWater will advise applicants if a loss adjustment will be required.

### Trading Caps

There are no Trading Caps in the scheme.

Approval may be given of the temporary transfer of a volume of water provided that the total water use for each zone does not exceed the maximum allowable water use volume provided by Department of Environment and Resource Management, as indicated in the below table; current as at June 2007 (subject to change).

Zone	Maximum allowable water use volume (ML)
Upper Pioneer zone group	38750
Lower Pioneer zone group	51650
Zone Teemburra 01	6575
Zone Cattle 01	9280
Zone Cattle 02	4610
Zone Silver/McGregor 01	6000
Zone Pioneer 04	4650
Zone Pioneer 03	16000
Zone Pioneer 02	27300
Zone Pioneer 01	48100
Zone Bakers 01	6000

### Transfer Adjustment Fee

A Transfer Adjustment Fee, equal to the value of SunWater's applied irrigation price subsidy, will be payable where water is transferred from a regulated irrigation pricing use to a non-irrigation use. It is the responsibility of the parties to any such transfer to contact SunWater to ascertain this fee in advance of settlement.

A Transfer Adjustment Fee, equal to the value of any other SunWater subsidy or discount to full commercial pricing, will also be payable where water is transferred from any other subsidised use to a non-subsidised use. Again, it is the responsibility of the parties to any such transfer to contact SunWater to ascertain this fee in advance of settlement.

### Other

Additional restrictions on temporary transfers may be applied, for example, in extremely dry conditions or when there is a marked transfer of water to high loss areas, at SunWater's discretion.