Resource Operations Licence Water Act 2000



Name of licence

Lower Fitzroy Water Supply Scheme Resource Operations Licence

Holder

Sunwater Limited

Water plan

The licence relates to the Water Plan (Fitzroy Basin) 2011.

Water infrastructure

The water infrastructure to which the licence relates is detailed in Attachment 1.

Authority to interfere with the flow of water

The licence holder is authorised to interfere with the flow of water to the extent necessary to operate the water infrastructure to which the licence relates.

Authority to use watercourses to distribute water

The licence holder is authorised to use the water courses listed in Table 1 for the distribution of supplemented water, including sections of tributaries where supplemented water is accessible.

Table 1 – Use of watercourses for distribution

Watercourse	Description
Fitzroy River	From the upstream limit of Eden Bann Weir (AMTD 183.4 km) to the Fitzroy Barrage (AMTD 59.6 km) for the distribution of supplemented water, including sections of tributaries where supplemented water is accessible.

Conditions

1. Requirement for operations manual

- **1.1.** The licence holder must operate in accordance with an approved operations manual.
- 1.2. The approved operations manual must include—
 - 1.2.1.operating rules for water infrastructure;
 - 1.2.2. water sharing rules; and
 - 1.2.3. seasonal water assignment rules.

2. Environmental management rules

2.1. The licence holder must comply with the requirements as detailed in Attachment 2.

3. Metering

3.1. The licence holder must meter the taking of water under all water allocations and seasonal water assignments managed under this licence.

4. Monitoring and reporting requirements

- **4.1.** The licence holder must carry out and report on the monitoring requirements as set out in Attachment 3.
- **4.2.** The licence holder must provide any monitoring data required under condition 4.1 to the chief executive within a stated time upon request.
- **4.3.** The licence holder must ensure that the monitoring, including the measurement, collection, analysis and storage of data, is consistent with the Water Monitoring Data Collection Standards¹.
- **4.4.** The licence holder must ensure that the transfer of data and reporting are consistent with the Water Monitoring Data Reporting Standards¹.

¹ The Water Monitoring Data Collection Standards and the Water Monitoring Data Reporting Standards can be accessed online at www.business.qld.gov.au

5. Other conditions

- **5.1.** The operating and supply arrangements, and the monitoring required under this licence, do not apply in situations where implementing the rules or meeting the requirements would be unsafe to a person or persons. In these circumstances, the licence holder must comply with the requirements for operational or emergency reporting prescribed in Attachment 3.
- **5.2.** The licence holder may at any time submit an interim program or an amendment to an existing program to the chief executive for approval in accordance with Attachment 4, if the holder proposes to operate in a way that does not meet the requirements of this licence.
- **5.3.** Where there is conflict between the requirements of this licence and an interim program, the program prevails for the time it is in place.
- **5.4.** The licence holder is required to collect and make publicly available through an industry accepted digital channel, updated at least monthly, details of each seasonal water assignment managed under this licence, including the sale price, the volume of water assigned and the location of where the water was assigned to and from.
- **5.5.** The licence holder must provide the chief executive information about seasonal water assignments as directed by the chief executive within the stated time upon request¹.

This Resource Operations Licence is subject to the conditions attached.

Commencement of licence

The licence took effect on 18 May 2006.

Granted on 18 May 2006. Amended under section 186 of the *Water Act 2000* on 10 January 2022.

Jarrod Cowley-Grimmond
Executive Director, Divisional Support

Attachment 1

Infrastructure details for Lower Fitzroy Water Supply Scheme

Table 1 – Eden Bann Weir—Fitzroy River AMTD 141.2 km

Table 1 - Lucii Ballii Well-	—FITZFOY RIVER AINTO 141.2 KM
Description of water infra	structure
Main embankment	Mass concrete gravity weir.
Full supply level	EL 14.5 m AHD.
Fixed crest level	EL 14.5 m AHD.
Saddle dam(s)	Nil.
Fabridams	Nil.
Gates	Nil.
Storage volume and surfa	ce area
Full supply volume	35 900 ML.
Dead storage volume	9650 ML.
Surface area/elevation and storage volume/elevation relationship	Department of Primary Industries (Water Resources) Drawing No's. A3-110383 and A3-110384.
Spillway arrangement	
Description of works	Two-level concrete spillway.
Spillway level	High level crest EL 14.8 m AHD. Low level crest EL 14.5 m AHD.
Spillway width	High level crest: 180 metres on right abutment. Low level crest: 90 metres on left abutment.
Discharge characteristics	Not available.
River inlet/outlet works	
Description of works	Inlet structure through 1200 mm by 1200 mm sluice gate to 1500 mm by 1500 mm box culvert.
Multi-level inlet	Works can accommodate selective withdrawal.
Cease to flow level	EL 7.25 metres AHD.
Discharge characteristics	Water Resources Drawing No. A3-101635.
Fish transfer system	
Description of works	Fishlock located near the left bank adjacent to the outlet works.
Local supply area/level	
Local Supply Level	EL 9.55 m AHD.
Local Supply Area	Eden Bann Weir pond and downstream, but excluding, Fitzroy Barrage pond.

Attachment 2 Environmental management rules

1 Quality of water released

Where a storage is fitted with multi-level inlet works, the licence holder must draw water from the inlet level that optimises the quality of water released.

2 Change in rate of release from infrastructure

The licence holder must minimise the occurrence of adverse environmental impacts by ensuring that any change in the rate of release of water from a storage into a watercourse occurs incrementally.

Attachment 3 Licence holder monitoring and reporting

Part 1 Monitoring requirements

Division 1 Water quantity

1 Stream flow and storage water level data

- (1) The licence holder must record water level and volume data, and stream flow data in accordance with Attachment 3, Table 1.
- (2) Infrastructure inflows may be determined based upon an infrastructure inflow derivation technique supplied by the licence holder and approved by the chief executive.

Table 1 - Locations where continuous water data recording required

Water level and volume data	Daily flow data
_	Eden Bann Weir inflow*
Eden Bann Weir headwater (AMTD 141.2 km)	_
_	Eden Bann Weir tailwater

^{*}Methodology already approved by the chief executive.

2 Releases from storages

- (1) The licence holder must measure and record for each release of water from Eden Bann Weir—
 - (a) the daily volume released; and
 - (b) the release rate, and for any change in release rate—
 - (i) the date and time of the change; and
 - (ii) the new release rate; and
 - (c) the reason for each release.
- (2) In addition to the requirements under subsection (1), for storage outlets with selective withdrawal capabilities, the licence holder must record—
 - (a) the inlet level used for each release of water; and
 - (b) the reason for deciding to release from that particular inlet level.

3 Use of waterholes

For each day that supplemented water is taken from a waterhole, the licence holder must measure and record the level of the water in the waterhole when the waterhole is drawn down more than 0.5 metres below its cease to flow level.

4 Water diversions

- (1) The licence holder must measure and record the daily total volumes of water delivered to the Stanwell pipeline.
- (2) The methodology for determining the volume delivered must be approved by the chief executive.

5 Restrictions

The licence holder must record details of any restriction on volumes for each priority

group that may be supplied, including-

- (a) the start and end date; and
- (b) the volume of water to be supplied.

6 Water taken by water users

The licence holder must, on an annual basis, measure and record the total volume of water taken by each water user for each zone.

7 Seasonal water assignment of a water allocation

The licence holder, upon consent to a seasonal water assignment, must record details of seasonal water assignment arrangements, including—

- (a) the name of the assignee and the assignor;
- (b) the volume of the assignment;
- (c) the location—
 - (i) from which it was assigned;
 - (ii) to which it was assigned;
- (d) the effective date of the seasonal water assignment; and
- (e) the sale price

Division 2 Impact of infrastructure operation on natural ecosystems

8 Water quality

The licence holder must monitor and record water quality data in relation to relevant infrastructure listed in Attachment 1.

9 Bank condition

- (1) The licence holder must inspect banks for evidence of collapse and/or erosion identified within ponded areas of each storage listed in Attachment 1 and downstream reaches, following instances of—
 - (a) rapid water level changes; or
 - (b) large flows through storage, or
 - (c) other occasions when collapse and/or erosion of banks may be likely.
- (2) For subsection (1), downstream of the relevant infrastructure means the distance of influence of infrastructure operations.

10 Fish stranding

The licence holder must record and assess reported instances of fish stranding in watercourses and ponded areas associated with the operation of the infrastructure listed in Attachment 1 to determine if any instance is associated with the operation of that infrastructure.

Part 2 Reporting requirements

11 Reporting requirements

The licence holder must provide—

- (a) annual reports for the previous water year; and
- (b) operational or emergency reports.

Division 3 Annual reporting

12 Annual report

- (1) The licence holder must submit an annual report to the chief executive after the end of the water year.
- (2) The annual report must include—
 - (a) water quantity monitoring results required under Attachment 3, section 13;
 - (b) details of the impact of storage operation on natural ecosystems as required under Attachment 3, section 14;
 - (c) a discussion on any issues that arose as a result of the implementation and application of the rules and requirements of this licence; and
 - (d) a summary of sale price disclosure information and other seasonal water assignment information as per Attachment 3, Part 1, Division 1(7).

13 Water quantity monitoring

The licence holder must include in the annual report—

- (a) instances where any restrictions have been implemented, including—
 - (i) an evaluation of the effectiveness of the limitation or restriction procedures and outcomes; and
 - (ii) the date and value for each restriction;
- (b) details of seasonal water assignments, including—
 - (i) the total number of seasonal water assignments; and
 - (ii) the total volume of water seasonally assigned;
- (c) the total annual volume of water taken by all water users, specified by zone, including—
 - (i) the total volume of supplemented water taken;
 - (ii) the total volume of supplemented water entitled to be taken; and
 - (iii) the basis for determining the total volume entitled to be taken;
- (d) details of waterhole monitoring, which has been undertaken under Attachment 3, section 3;
- (e) all details of changes to the storage and delivery infrastructure or the operation of the storage and infrastructure that may impact on compliance with this licence;
- (f) details of any new monitoring devices used, such as equipment to measure stream flow; and
- (g) the details and status of any interim programs implemented under condition 5.2.

14 Impact of infrastructure operation on natural ecosystems

The licence holder must include in their annual report—

- (a) a summary of the environmental considerations made by the licence holder in making operational and release decisions;
- (b) a summary of the environmental outcomes of the decision, including any adverse environmental impacts;
- (c) a summary of bank condition and fish stranding monitoring and assessment, including—
 - results of investigations of bank slumping and/or erosion identified in the ponded areas and/or downstream of the storages;
 - (ii) results of any investigations of fish stranding downstream of the storages; and
 - (iii) changes to the operation of the storage to reduce instances of bank slumping and/or erosion or fish stranding; and
- (d) a discussion and assessment of the following water quality issues—
 - (i) thermal and chemical stratification in the storage;
 - (ii) contribution of the storage and its management to the quality of water released;
 - (iii) cyano-bacterial population changes in response to stratification in the storage; and
 - (iv) any proposed changes to the monitoring program as a result of evaluation of the data.

Division 4 Operational or emergency reporting

15 Operational or emergency reporting²

- The licence holder must notify the chief executive—
 - (a) within one business day of becoming aware of any of the following operational incidents—
 - (i) a non-compliance by the licence holder with the conditions of this licence:
 - (ii) instances of fish stranding, cyanobacterial growth or bank slumping within the ponded areas or downstream of the water infrastructure to which this licence relates;
 - (iii) a decision being made to introduce a reduced full supply level under section 399B of the *Water Supply (Safety and Reliability)*Act 2008; and
 - (b) of an emergency where, as a result of the emergency, the licence holder cannot comply with the conditions of this licence.
- (2) The licence holder must provide to the chief executive upon request, and within the timeframe requested, a report which includes details of—
 - (i) the incident or emergency;
 - (ii) the conditions under which the incident or emergency occurred;
 - (iii) any responses or activities carried out as a result of the incident or emergency; and

² This does not preclude requirements for dam safety under the *Water Supply (Safety and Reliability) Act 2008, Water Act 2000* and any other applicable legislation.

- (iv) in relation to an emergency only, any requirements under this licence that the licence holder is either permanently or temporarily unable to comply with due to the emergency.
- (3) The licence holder must—
 - (a) notify the chief executive within one business day—
 - (i) upon setting an initial announced allocation or resetting an announced allocation during the water year; and
 - (ii) with details of any arrangements for addressing circumstances where they are unable to supply water allocations;
 - (b) provide the chief executive with relevant supporting information used in making any decision under subsection (a)(i) and (ii).

Attachment 4 Interim programs

1 Submission of interim program

The licence holder may, at any time, submit an interim program to the chief executive for approval, including a timetable for returning to full compliance with the licence and interim arrangements.

2 Implementing and publishing interim program

Following approval of the program by the chief executive, the licence holder must—

- (a) implement and operate in accordance with the interim program; and
- (b) make public details of the interim program on its internet site.

Glossary

AHD The base Adopmid water water water Assignee Assignor Barrage A	Australian Height Datum, which references a level or height to a standard e level. Inpeted middle thread distance is the distance in kilometres, measured along the die of the watercourse, that a specific point in the watercourse is from the ercourse's mouth; or—if the watercourse is not a main watercourse—the ercourse's confluence with its main watercourse. In person or entity to whom an interest or right to water is being transferred — for mple, seasonally assigned. In person or entity who transfers an interest or right in water to an assignee — for mple, a seasonal assignment. In a rierrier constructed across a watercourse to prevent the inflow of tidal water. In a waterhole, the level at which water stops flowing from a waterhole over its vinstream control. In a dam or weir, the specified minimum volume of water within the ponded area are storage that cannot be released or used from the storage under normal rating conditions. Viriation level.
AMTD base Adop Midd wate wate wate Assignee The exar Assignor Earrage A base Cease to flow level For a dow For a Dead storage of th oper EL Elev Fish stranding wate sma also Full supply level barra Infra	e level. pted middle thread distance is the distance in kilometres, measured along the dle of the watercourse, that a specific point in the watercourse is from the ercourse's mouth; or—if the watercourse is not a main watercourse—the ercourse's confluence with its main watercourse. person or entity to whom an interest or right to water is being transferred – for mple, seasonally assigned. person or entity who transfers an interest or right in water to an assignee – for mple, a seasonal assignment. arrier constructed across a watercourse to prevent the inflow of tidal water. a waterhole, the level at which water stops flowing from a waterhole over its vistream control. a dam or weir, the specified minimum volume of water within the ponded area he storage that cannot be released or used from the storage under normal rating conditions.
AMTD midd wate wate wate wate water and water wa	dle of the watercourse, that a specific point in the watercourse is from the ercourse's mouth; or—if the watercourse is not a main watercourse—the ercourse's confluence with its main watercourse. It person or entity to whom an interest or right to water is being transferred – for mple, seasonally assigned. It person or entity who transfers an interest or right in water to an assignee – for mple, a seasonal assignment. It person or entity who transfers an interest or right in water to an assignee – for mple, a seasonal assignment. It person or entity who transfers an interest or right in water to an assignee – for mple, a seasonal assignment. It person or entity who transfers an interest or right in water to an assignee – for mple, a seasonal assignment. It person or entity who transfers an interest or right in water to an assignee – for mple, a seasonal assignment. It person or entity to whom an interest or right to water to an assignee – for mple, a seasonal assignment. It person or entity to whom an interest or right to water to an assignee – for mple, a seasonal assignment. It person or entity to whom an interest or right to water to an assignee – for mple, a seasonal assignment or entity who transferred – for mple, seasonally assigned in water to an assignee – for mple, a seasonal assignment or entity who transferred – for mple, seasonally assigned in water to an assignee – for mple, a seasonal assignment or entity who transferred – for mple, seasonally assigned in water to an assignment or mple, seasonally assigned in the person or entity to whom an interest or right to water is being transferred – for mple, seasonally assigned in the person or entity to whom an interest or right to water is being transferred – for mple, seasonally assigned in the person or entity to water seasonal assignment or entity to
Assignee exar Assignor The exar Barrage A ba Cease to flow level For a dow For a dow Dead storage of th oper EL Elev Fish stranding wate sma also Full supply level barra	mple, seasonally assigned. person or entity who transfers an interest or right in water to an assignee – for mple, a seasonal assignment. arrier constructed across a watercourse to prevent the inflow of tidal water. a waterhole, the level at which water stops flowing from a waterhole over its vinstream control. a dam or weir, the specified minimum volume of water within the ponded area he storage that cannot be released or used from the storage under normal rating conditions.
Assignor exar Barrage A ba Cease to flow level For a dow For a dow Dead storage of th oper EL Elev Fish stranding wate sma also Full supply level barray linfra valve	mple, a seasonal assignment. arrier constructed across a watercourse to prevent the inflow of tidal water. a waterhole, the level at which water stops flowing from a waterhole over its vinstream control. a dam or weir, the specified minimum volume of water within the ponded area he storage that cannot be released or used from the storage under normal rating conditions.
Cease to flow level For a dow For a dow Dead storage of the oper EL Elev Fish stranding wate sma also Full supply level barra Infra	a waterhole, the level at which water stops flowing from a waterhole over its instream control. a dam or weir, the specified minimum volume of water within the ponded area he storage that cannot be released or used from the storage under normal rating conditions.
dow For a Dead storage of the oper EL Elev Whe water small so of the oper Fish stranding The barral linfra valve.	Instream control. a dam or weir, the specified minimum volume of water within the ponded area ne storage that cannot be released or used from the storage under normal rating conditions.
Dead storage of the oper EL Elev Whe water small storage was also The barra linfra valve.	ne storage that cannot be released or used from the storage under normal rating conditions.
Fish stranding Full supply level Infra	vation level.
Fish stranding wate sma also The barra Infra	
barra barra lnira valve	en fish are stranded or left out of the water on the bed or banks of a ercourse, on infrastructure such as spillways and causeways or left isolated in all and/or shallow pools, from which they cannot return to deeper water. This applies to other aquatic species such as platypus and turtles.
valve	specified maximum volume of water within the ponded area of a dam, weir or rage, which corresponds to the full supply level.
	astructure comprised of an entrance channel, intake structure, and gate or which allow for water to be taken from the ponded area of a dam, weir or age and discharged via an outlet into the watercourse downstream of the age.
the z an A For a Location abut may For a	a water allocation, means— zone from which water under the water allocation can be taken; or AMTD within a zone, from which water under the water allocation can be taken. a water licence, means the section of the watercourse, lake, spring or aquifer tting or contained by the land described on the water licence at which water be taken. a water licence to take overland flow water, means land described on the er licence at which water may be taken.
Megalitre (ML) One	e million litres.
() I	arrangement on a dam or weir that allows stored water to be released vnstream.
Ponded area Area	a of inundation at full supply level of a storage.
sche	rouping of water allocations for taking supplemented water from a water supply eme with the same Water Allocation Security Objective (WASO).
the o	ter from a dam or weir that passes downstream from the dam or weir through dam or weir outlet works.
inclu	flow of water immediately downstream of a dam, weir or barrage. Tailwater udes all water passing the infrastructure – for example, controlled releases and
Water user The	ontrolled overflows.